


Oreadex

Massager & Beauty



USER MANUAL

Vibration Massager

Thank you for purchasing Oreadex product.
Please read this manual carefully before first use and
keep it properly for future reference.


Precautions

Please read this user manual carefully for correct and safe use of this massager.

1. The vibrator is a personal massager and not a medical device.
2. Do not use or store at the place where temperature is high, such as dusty place, kitchen, or where there are many flammable materials or humid area, as this may shorten the life expectancy of the device.
3. This product is waterproof, you can use it in the bathroom but please do not place or store unit where it can fall or be pulled into a tub.
4. Do not clean the vibrator with chemicals, thinner, benzene, nail polish remover, or any solvents which could damage the device.
5. People who are receiving the medical treatment or have received operations should not use this product.
6. Please stop using this product when you feel any discomfort.
7. This product is designed for household use only. It should not be used in diagnosing, treating or any other commercial purposes.
8. Do not use the vibrator massage on open skin eruptions, swollen or inflamed areas, or around your chest & throat area.
9. Please clean the product with a soft, damp cloth or water after each use.

10. Do not use when plugged in and charging. When its charging, please keep the product dry and insert the DC plug into the port gently.
11. Do not leave product unattended when plugged in. Unplug from outlet when not in charging.

Structure Description



1. Power On/Off
2. Vibration Mode
3. Speed Levels
4. Control Interface
5. Waterproof Charging Port
6. Glossy ABS
7. Flexible Massage Head
8. Charging Cable

How to use

1. Press the On/Off button to start massager.
2. Press the Vibration Mode button to switch different vibration patterns, and press Speed Levels button to control the intensity of the vibrator.
3. Use the massager to relieve tension and relax tired muscles by pressing the massage head into or against different areas of your body.
4. The massager is water resistant and can be used in the shower or bathroom. (DO NOT SUBMERGE.)

Charging

1. When the massager's vibration is weak, or does not working but the LED light is still on, please recharge.
2. Insert the DC plug into the DC Charging Port of the vibrator.
3. Insert the USB Charging Cable to a USB power outlet. The LED on the interface of vibrator light up and flashing to indicate it is charging. When fully charged about 2 hours, the LED light will stop flashing.

Specifications

Product Name: Vibration Massager

Product Size: 41*41*200mm

Product Weight: 185g

Battery Type: Li-Polymer /500mAh

Input: 5V=== 500mAh

Battery Life: Approx. 1.5 hours

Charging Time: Approx. 2 hours